

# Origo™ TA23



**Instruction manual**

<b>1 INTRODUCTION .....</b>	<b>3</b>
1.1 Control panel TA23 .....	3
<b>2 TIG WELDING .....</b>	<b>4</b>
2.1 Settings .....	4
2.2 Symbol and Function explanations .....	4
2.3 Hidden TIG functions .....	7
<b>3 MMA WELDING .....</b>	<b>8</b>
3.1 Settings .....	8
3.2 Symbol and Function explanations .....	8
3.3 Hidden MMA functions .....	9
<b>4 FAULT CODES .....</b>	<b>10</b>
4.1 List of fault codes .....	10
4.2 Fault code descriptions .....	11
<b>5 ORDERING SPARE PARTS .....</b>	<b>11</b>
<b>ORDER NUMBER .....</b>	<b>12</b>

# 1 INTRODUCTION

The manual describes the use of **TA23** control panel.

For general information about operation see user's instructions for the power source.












When mains power is supplied the unit runs a self diagnosis of the LEDs and the display, the program version is displayed and in this example the program version is 0.18A

**NOTE!** Differences in the panel function may occur, depending on in which product it is installed.

Instruction manuals in other languages can be downloaded from the website, [www.esab.com](http://www.esab.com).

## 1.1 Control panel TA23



- 1 Knob for setting current (A) or time (s)
- 2 Display
- 3 Choice of welding method TIG  or MMA 
- 4 Choice of HF start  or LiftArc™ 
- 5 Choice of 2-stroke  or 4-stroke 
- 6 Setting from panel  or for connecting remote control unit 
- 7 Display of VRD function (*reduced open-circuit voltage*) is active or inactive
- 8 Indication of which parameter is shown in the display (current or seconds)

**9** Choice of setting parameter, see page 4

**10** Indication of selected setting parameter, see page 4.

Measured value in the display for welding current A, is arithmetic average value = rectified average value.

## 2 TIG WELDING

### 2.1 Settings

#### TIG without pulsing

Function	Setting range	Default value
HF / LiftArc <sup>TM</sup> 1)	HF or LiftArc <sup>TM</sup>	LiftArc <sup>TM</sup>
2/4-stroke 1)	2 stroke or 4 stroke	2 stroke
Gas pre flow time 2)	0 -5 s	0.5 s
Slope up-time	0 -10 s	0.0 s
Slope down time	0 -10 s	1.0 s
Gas post flow time	0 -25 s	5.0 s
Current	4 A -max 3)	60 A
Active panel	OFF or ON	ON
Remote control unit	OFF or ON	OFF
Min current 2)	0-99%	0%
VRD	-	-

1) These functions cannot be changed while welding is in progress

2) These functions are hidden TIG functions, see description point 2.3.

3) The setting range is dependent on the power source used.

### 2.2 Symbol and Function explanations




#### TIG welding

TIG welding melts the metal of the workpiece, using an arc struck from a tungsten electrode, which does not melt itself. The weld pool and the electrode are protected by shielding gas.

#### Parameter settings

1. Slope up
2. Welding current
3. Slope down
4. Gas post flow time



## Slope up

The slope up function means that, when the TIG arc strikes, the current rises slowly to the set value. This provides 'gentler' heating of the electrode, and gives the welder a chance to position the electrode properly before the set welding current is reached.

## Welding current

A higher current produces a wider weld pool, with better penetration into the workpiece.

## Slope down

TIG welding uses "slope down", by which the current falls 'slowly' over a controlled time, to avoid craters and/or cracks, when a weld is finished.

## Gas post-flow


This controls the time during which shielding gas flows after the arc is extinguished.

## HF start

The HF start function strikes the arc by means of a spark from the electrode to the workpiece as the electrode is brought closer to the workpiece.


## LiftArc™

With LiftArc™ the arc strikes when the tungsten electrode is brought into contact with the workpiece and then lifted away from it.



*Striking the arc with the LiftArc function™. Step 1: the electrode is touched on to the workpiece. Step 2: the trigger switch is pressed, and a low current starts to flow. Step 3: the welder lifts the electrode from the workpiece: the arc strikes, and the current rises automatically to the set value.*


**↓ ↑ 2 stroke**



*Functions when using 2 stroke control of the welding torch.*

In the 2 stroke control mode, pressing the TIG torch trigger switch (1) starts gas pre-flow (if used) and strikes the arc. The current rises to the set value (as controlled by the slope up function, if in operation). Releasing the trigger switch (2) reduces the current (or starts slope down if in operation) and extinguishes the arc. Gas post-flow follows if it is in operation.

**↕ ↕ 4 stroke**



*Functions when using 4 stroke control of the welding torch.*

In the 4 stroke control mode, pressing the trigger switch (1) starts gas pre-flow (if used). At the end of the gas pre-flow time, the current rises to the pilot current (a few ampere), and the arc is struck. Releasing the trigger switch (2) increases the current to the set value (with slope up, if in use). When the trigger switch is pressed in (3) the current returns to the set pilot current (with "slope down" if in use). When the trigger switch is released again (4) the arc is extinguished and any gas post flow occurs.



**Active panel**

Settings are made from the control panel.



**Remote control unit**

Settings are made from the remote control unit.

The remote control unit must be connected to the remote control unit socket on the machine before activation. When the remote control unit is activated the panel is inactive.



## VRD (Voltage Reducing Device)

The VRD function ensures that the open-circuit voltage does not exceed 35 V when welding is not being carried out. This is indicated by a lit VRD LED.

The VRD function is blocked when the system senses that welding has started.


If the VRD function is activated and the open-circuit voltage exceeds the 35 V limit, this is indicated by an error message (16) appearing in the display and welding cannot be started whilst the error message is displayed.

Contact an authorised ESAB service technician to activate the function.


## 2.3 Hidden TIG functions

There are hidden functions in the control panel.



To access the functions, press  for 5 seconds. The display shows a letter and a value. Select function by pressing the right arrow. The knob is used to change the value of the selected function.



To access hidden functions, press  for 5 seconds.

### Control panel TA23

Function	Settings
A = gas pre-flow	0 - 5 s
I = min current	0 - 99%



### Gas pre-flow

This controls the time during which shielding gas flows before the arc is struck.

### Min current

Used to set the minimum current for the remote control.

If the max current is 100 A and the min current is to be 50 A, set the hidden function min current to 50%.

If the max current is 100 A and the min current is to be 90 A, set the min current to 90%.

## 3 MMA WELDING

### 3.1 Settings

Function	Setting range	Default value
Current	16 A -max <sup>1)</sup>	100 A
Hotstart <sup>2)</sup>	0 - 99	0
Arc force <sup>2)</sup>	0 - 99	5
Drop welding <sup>2)</sup>	0=OFF or 1=ON	0
Welding regulator <sup>2)</sup>	1=ArcPlus™ II or 0=ArcPlus™	1
Active panel	OFF or ON	ON
Remote control unit	OFF or ON	OFF
Min current <sup>2)</sup>	0-99%	0%
VRD	-	-

<sup>1)</sup> The setting range is dependent on the power source used.

<sup>2)</sup> These functions are hidden functions, see description point 3.3.

### 3.2 Symbol and Function explanations



#### MMA welding

MMA welding may also be referred to as welding with coated electrodes. Striking the arc melts the electrode, and its coating forms protective slag.



#### Active panel

Settings are made from the control panel.



#### Remote control unit

Settings are made from the remote control unit.

The remote control unit must be connected to the remote control unit socket on the machine before activation. When the remote control unit is activated the panel is inactive.



#### VRD (Voltage Reducing Device)

The VRD function ensures that the open-circuit voltage does not exceed 35 V when welding is not being carried out. This is indicated by a lit VRD LED.

The VRD function is blocked when the system senses that welding has started.

If the VRD function is activated and the open-circuit voltage exceeds the 35 V limit, this is indicated by an error message (16) appearing in the display and welding cannot be started whilst the error message is displayed.


Contact an authorised ESAB service technician to activate the function.




### 3.3 Hidden MMA functions

There are hidden functions in the control panel.



To access the functions, press  for 5 seconds. The display shows a letter and a value. Select function by pressing the right arrow. The knob is used to change the value of the selected function.



To access hidden functions, press  for 5 seconds.

#### Control panel TA23

Function	Settings
<b>C</b> = Arc Force	0 - 99%
<b>d</b> = drop welding	<b>0</b> = OFF; <b>1</b> = ON
<b>F</b> = welding regulator	<b>1</b> = ArcPlus™ II; <b>0</b> = ArcPlus™
<b>H</b> = Hotstart	0 - 99%
<b>I</b> = min current	0 - 99%



#### Arc force

The arc force is important in determining how the current changes in response to a change in the arc length. A lower value gives a calmer arc with less spatter.

#### Drop welding

Drop welding can be used when welding with stainless electrodes. The function involves alternately striking and extinguishing the arc in order to achieve better control of the supply of heat. The electrode needs only to be raised slightly to extinguish the arc.

#### Welding regulator

Welding regulator is a type of control that produces a more intense, more concentrated and calmer arc. It recovers more quickly after a spot short-circuit, which reduces the risk of the electrode becoming stuck.

- ArcPlus™ (0) is recommended with basic type of electrode
- ArcPlus™ II (1) is recommended with rutile and cellulosic type of electrode



#### Hot start

Hot start increases the weld current for an adjustable time at the start of welding, thus reducing the risk of poor fusion at the beginning of the joint.

#### Min current

Used to set the minimum current for the remote control.

If the max current is 100 A and the min current is to be 50 A, set the hidden function min current to 50%.

If the max current is 100 A and the min current is to be 90 A, set the min current to 90%.

---

## **4 FAULT CODES**

---

The fault code is used to indicate that a fault has occurred in the equipment. It is indicated in the display by an E followed by a fault code number.

A unit number is displayed to indicate which unit has generated the fault.

Fault code numbers and unit numbers are shown alternately.

If several faults have been detected only the code for the last occurring fault is displayed. Press any function button or turn the knob to remove the fault indication from the display.

NOTE! If the remote control is activated, deactivate the remote control by pressing



to remove the fault indication.

### **4.1 List of fault codes**

**U 0** = welding data unit

**U 2** = power source

**U 1** = cooling unit

**U 4** = remote control unit

## 4.2 Fault code descriptions

Below are described event codes at which the user himself can take corrective action. If any other code is shown, send for a service technician.

Fault code	Description
<b>E 5</b>	<b>Intermediate DC voltage outside limits</b> The mains power supply is too high or too low. Too high a voltage can be due to severe transients on the mains power supply or to a weak power supply (high inductance of the mains power supply or a phase missing). <b>Action:</b> Send for a service technician.
<b>E 6</b>	<b>High temperature</b> The thermal overload cut-out has tripped. The current welding process is stopped and cannot be restarted until the temperature has fallen. <b>Action:</b> Check that the cooling air inlets or outlets are not blocked or clogged with dirt. Check the duty cycle being used, to make sure that the equipment is not being overloaded.
<b>E 12</b>	<b>Communication error (warning)</b> Less serious interference on the CAN bus. <b>Action:</b> Check that there are no faulty units connected on the CAN bus. Check the cables. Send for a service technician if the fault persists.
<b>E 14</b>	<b>Communication error (bus off)</b> Serious interference on the CAN bus. <b>Action:</b> Check that there are no faulty units connected on the CAN bus. Check the cables. Send for a service technician if the fault persists.
<b>E 16</b>	<b>High open-circuit voltage</b> Open circuit voltage has been too high. <b>Action:</b> Turn off the mains power supply to reset the unit. Send for a service technician if the fault persists.
<b>E 29</b>	<b>No cooling water flow</b> The flow monitor switch has tripped. The current welding process is stopped and starting is prevented. <b>Action:</b> Check the cooling water circuit and the pump.
<b>E 41</b>	<b>Lost contact with the cooling unit</b> The welding data unit has lost contact with the cooling unit. The welding process stops. <b>Action:</b> Check the wiring. Send for a service technician if the fault persists.

## 5 ORDERING SPARE PARTS

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.

## TA23

### Order number



Ordering no.	Denomination
0459 773 884	Control panel Origo™ TA23
0460 032 170	Instruction manual SE
0460 032 171	Instruction manual DK
0460 032 172	Instruction manual NO
0460 032 173	Instruction manual FI
0460 032 174	Instruction manual GB
0460 032 175	Instruction manual DE
0460 032 176	Instruction manual FR
0460 032 177	Instruction manual NL
0460 032 178	Instruction manual ES
0460 032 179	Instruction manual IT
0460 032 180	Instruction manual PT
0460 032 181	Instruction manual GR
0460 032 182	Instruction manual PL
0460 032 183	Instruction manual HU
0460 032 184	Instruction manual CZ
0460 032 185	Instruction manual SK
0460 032 186	Instruction manual RU
0460 032 189	Instruction manual EE
0460 032 190	Instruction manual LV
0460 032 191	Instruction manual SI
0460 032 192	Instruction manual LT
0459 839 003	Spare parts list

Instruction manuals and the spare parts list are available on the Internet at [www.esab.com](http://www.esab.com)

## This image shows a full page of white paper with horizontal dashed lines, typical of primary school writing paper. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## This image shows a full page of white paper with horizontal dashed lines, typical of primary school writing paper. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## This image shows a full page of white paper with horizontal dashed lines, typical of primary school writing paper. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

# ESAB subsidiaries and representative offices

<b>Europe</b> <b>AUSTRIA</b> ESAB Ges.m.b.H Vienna-Liesing Tel: +43 1 888 25 11 Fax: +43 1 888 25 11 85  <b>BELGIUM</b> S.A. ESAB N.V. Brussels Tel: +32 2 745 11 00 Fax: +32 2 745 11 28  <b>BULGARIA</b> ESAB Kft Representative Office Sofia Tel/Fax: +359 2 974 42 88  <b>THE CZECH REPUBLIC</b> ESAB VAMBERK s.r.o. Vamberk Tel: +420 2 819 40 885 Fax: +420 2 819 40 120  <b>DENMARK</b> Aktieselskabet ESAB Herlev Tel: +45 36 30 01 11 Fax: +45 36 30 40 03  <b>FINLAND</b> ESAB Oy Helsinki Tel: +358 9 547 761 Fax: +358 9 547 77 71  <b>FRANCE</b> ESAB France S.A. Cergy Pontoise Tel: +33 1 30 75 55 00 Fax: +33 1 30 75 55 24  <b>GERMANY</b> ESAB GmbH Solingen Tel: +49 212 298 0 Fax: +49 212 298 218  <b>GREAT BRITAIN</b> ESAB Group (UK) Ltd Waltham Cross Tel: +44 1992 76 85 15 Fax: +44 1992 71 58 03  ESAB Automation Ltd Andover Tel: +44 1264 33 22 33 Fax: +44 1264 33 20 74  <b>HUNGARY</b> ESAB Kft Budapest Tel: +36 1 20 44 182 Fax: +36 1 20 44 186  <b>ITALY</b> ESAB Saldatura S.p.A. Bareggio (Mi) Tel: +39 02 97 96 8.1 Fax: +39 02 97 96 87 01  <b>THE NETHERLANDS</b> ESAB Nederland B.V. Amersfoort Tel: +31 33 422 35 55 Fax: +31 33 422 35 44	<b>NORWAY</b> AS ESAB Larvik Tel: +47 33 12 10 00 Fax: +47 33 11 52 03  <b>POLAND</b> ESAB Sp. z o.o. Katowice Tel: +48 32 351 11 00 Fax: +48 32 351 11 20  <b>PORTUGAL</b> ESAB Lda Lisbon Tel: +351 8 310 960 Fax: +351 1 859 1277  <b>ROMANIA</b> ESAB Romania Trading SRL Bucharest Tel: +40 316 900 600 Fax: +40 316 900 601  <b>RUSSIA</b> LLC ESAB Moscow Tel: +7 (495) 663 20 08 Fax: +7 (495) 663 20 09  <b>SLOVAKIA</b> ESAB Slovakia s.r.o. Bratislava Tel: +421 7 44 88 24 26 Fax: +421 7 44 88 87 41  <b>SPAIN</b> ESAB Ibérica S.A. Alcalá de Henares (MADRID) Tel: +34 91 878 3600 Fax: +34 91 802 3461  <b>SWEDEN</b> ESAB Sverige AB Gothenburg Tel: +46 31 50 95 00 Fax: +46 31 50 92 22  ESAB international AB Gothenburg Tel: +46 31 50 90 00 Fax: +46 31 50 93 60  <b>SWITZERLAND</b> ESAB AG Dietikon Tel: +41 1 741 25 25 Fax: +41 1 740 30 55  <b>UKRAINE</b> ESAB Ukraine LLC Kiev Tel: +38 (044) 501 23 24 Fax: +38 (044) 575 21 88	<b>North and South America</b> <b>ARGENTINA</b> CONARCO Buenos Aires Tel: +54 11 4 753 4039 Fax: +54 11 4 753 6313  <b>BRAZIL</b> ESAB S.A. Contagem-MG Tel: +55 31 2191 4333 Fax: +55 31 2191 4440  <b>CANADA</b> ESAB Group Canada Inc. Mississauga, Ontario Tel: +1 905 670 02 20 Fax: +1 905 670 48 79  <b>MEXICO</b> ESAB Mexico S.A. Monterrey Tel: +52 8 350 5959 Fax: +52 8 350 7554  <b>USA</b> ESAB Welding & Cutting Products Florence, SC Tel: +1 843 669 44 11 Fax: +1 843 664 57 48  <b>Asia/Pacific</b> <b>AUSTRALIA</b> ESAB South Pacific Archerfield BC QLD 4108 Tel: +61 1300 372 228 Fax: +61 7 3711 2328  <b>CHINA</b> Shanghai ESAB A/P Shanghai Tel: +86 21 2326 3000 Fax: +86 21 6566 6622  <b>INDIA</b> ESAB India Ltd Calcutta Tel: +91 33 478 45 17 Fax: +91 33 468 18 80  <b>INDONESIA</b> P.T. ESABindo Pratama Jakarta Tel: +62 21 460 0188 Fax: +62 21 461 2929  <b>JAPAN</b> ESAB Japan Tokyo Tel: +81 45 670 7073 Fax: +81 45 670 7001  <b>MALAYSIA</b> ESAB (Malaysia) Snd Bhd USJ Tel: +603 8023 7835 Fax: +603 8023 0225  <b>SINGAPORE</b> ESAB Asia/Pacific Pte Ltd Singapore Tel: +65 6861 43 22 Fax: +65 6861 31 95	<b>SOUTH KOREA</b> ESAB SeAH Corporation Kyungnam Tel: +82 55 269 8170 Fax: +82 55 289 8864  <b>UNITED ARAB EMIRATES</b> ESAB Middle East FZE Dubai Tel: +971 4 887 21 11 Fax: +971 4 887 22 63  <b>Africa</b> <b>EGYPT</b> ESAB Egypt Dokki-Cairo Tel: +20 2 390 96 69 Fax: +20 2 393 32 13  <b>SOUTH AFRICA</b> ESAB Africa Welding & Cutting Ltd Durbanvill 7570 - Cape Town Tel: +27 (0)21 975 8924  <b>Distributors</b> <i>For addresses and phone numbers to our distributors in other countries, please visit our home page</i>  <a href="http://www.esab.com">www.esab.com</a>
---	--	--	---



[www.esab.com](http://www.esab.com)

